#### **Relief Valve Research for Refuge Alternatives**



#### **Relief Valve Pressure / Flow Test Stand**

#### NIOSH research concluded that

- Relief valve concepts can meet regulatory specifications for pressure relief and flow
  - 0.18 psi above mine atmospheric pressure
  - $_{\rm o}$  12.5 CFM per person
- Additional testing is needed to assess the survivability of relief valves subjected to blast conditions (15 psi overpressure for 0.2 seconds)
- Blast valves may be needed to supplement and protect relief valves

### **Relief Valve Research**

- Objectives
  - Assess the ability of relief values to survive an explosion
  - Determine design factors critical to their reliability
  - Investigate blast values as a supplemental protection
- Assessment Plan
  - Subject relief valves to a simulated blast
  - Evaluate pre- and post-test performance metrics (flow, pressure, and leakage)
  - Compare pre- and post-test 3D surface scans

#### **Pre-test 3D Relief Valve Scan**



#### **Valve Types**

## **Check Valves**

- RA applications
- Normally closed
- Single-direction flow
- Open at pressure threshold

## **Blast Valves**

- Bomb shelters
- Normally open
- Bi-directional flow
- Close at pressure threshold





#### **Test Valves**



4-inch manufactured RA relief valve





2-inch manufactured RA relief valve





4-inch steel butterfly check valve

#### **Test Valves**



6-inch PVC swing check valve

4-inch PVC swing check valve 4-inch cast iron swing check valve

4-inch cast iron butterfly check valve

#### **Test Valves**



4-inch blast valve



9-inch blast valve

## **Test Facility**

- The MSHA Approval and Certification Center (A&CC) has a facility used to test explosionproof components for approval
- This facility is equipped with a test gallery capable of generating and igniting methaneair mixtures within an enclosure





#### **Overpressure Control**

• A modified enclosure and pressure control valve were used to simulate a blast



#### **Overpressure Waveforms**



- 7.3% methane by volume
  - 14.5 psig (+/- 2 psig)
  - ~0.9-second duration

#### 9.6% methane by volume

- 17.5 psig (+/- 3 psig)
- ~0.5-second duration

### **Relief Valve Testing**

- Relief valves were attached to the explosion-proof box using a custom adaptor plate and standard pipe fittings
- Various transducers were employed to record strain, temperature, pressure, and acceleration
- Video monitoring was conducted to capture and observe points of leakage, surface deformation, and failure



4-inch Cast Iron Swing Check Valve - 7.3% Methane Test

# NIOSH Valve 4 shot 2 10 - 31 - 2018**Real Time**

4-inch Steel Butterfly Check Valve - 7.3% Methane Test

# NIOSH Valve 2 10 - 30 - 2018Real Time

#### **Results and Conclusions**

- Seven relief valves were subjected to the 7.3% methane test
- Overpressures ranged from 12.7-21.4 psig and ~0.9 seconds in duration
- No catastrophic failures occurred in the first round of testing
- All seven relief values appeared to be intact upon visual inspection
- Video revealed leakage from the 4-inch steel butterfly check valve



### **Future Work**

- Pre- and post-test metrics will be compared to
  - Quantify changes in valve performance (flow, pressure, and leakage)
  - Measure any permanent changes in physical shape (3D scans)
- Pressure, temperature, strain, and acceleration data will be used for engineering analysis
- Finite element (FE) modeling will be performed and validated using test data
- Blast valves will be assessed as a supplemental protection to relief valves
- Enclosure volume will be investigated for achieving faster durations, 0.1 seconds and less
- In-test valve leakage should be further investigated in order to quantify the potential for contamination ingress
- Valves should be tested in the open position, as when flowing

**Questions?** 

## Thank you!

## John Homer JHomer@cdc.gov 412-386-5289







Disclaimer: The findings and conclusions in this report are those of the author(s) and do not necessarily represent the views of the National Institute for Occupational Safety and Health. Mention of any company or product does not constitute endorsement by NIOSH.